



PIPETEC® LEAD-FREE PRESS FITTINGS



- **Lead-free**
Ready for the European
Drinking Water Directive 2024



- **Extensive portfolio**



- **Easy to use**



- **Break-proof**
by additional reinforcements



- **LBP – Leak before
pressed feature**
dimensions 16-32mm



- **TH- and U-Pressprofile**
16-32 mm



Bags

made from **50%** recycled material



Resealable carton box

Also available in our
new **ECO-BOX**



REACH compliant








Dezincification resistant





► AREAS OF APPLICATION

-  Drinking water installations
-  Underfloor/wall heating
-  Underfloor/wall cooling
-  Radiator connection
-  Oil-free compressed air up to 10 bar








► CERTIFICATIONS

-  DVGW
-  IMA
-  ÜA
-  EN ISO 21003

► ADVANTAGES

- Very good resistance coefficient (zeta) for lower pressure loss
- Unobstructed passage and virtually no flow noise
- All materials are safe for use with drinking water and are on the UBA positive list
- Two O-rings for optimal safety
- Strong plastic guide ring for secure press fittings even in confined spaces
- Three inspection windows in the stainless steel sleeve for checking the depth of insertion
- The forced leakage of the system ensures that connections that have not been pressed can be located even during the pressure test (Dimension 16-32 mm)

► PROPERTIES

-  DVGW DW-8501BS5049
-  Durability: 10 bar / 70°C / 50 years
-  Maximum operating temperature 95°C
-  TH press contour (up to 63 mm) and U contour (up to 32 mm)
-  Leak before pressed feature (dimensions 16-32 mm)
-  EN 10226-1 thread
-  Brass: CW 724R



**PRESS CONNECTOR WITH MALE THREAD**

GTIN NO. (EAN)	ITEM NO.	SIZE	MATERIAL	
4255750506289	ECOPFUA1604	16 x 2 - 1/2"	Brass	60
4255750506296	ECOPFUA2004	20 x 2 - 1/2"	Brass	60
4255750506302	ECOPFUA2005	20 x 2 - 3/4"	Brass	50
4255750506319	ECOPFUA2605	26 x 3 - 3/4"	Brass	25
4255750506326	ECOPFUA2606	26 x 3 - 1"	Brass	25
4255750506333	ECOPFUA3206	32 x 3 - 1"	Brass	15
4255750506340	ECOPFUA3207	32 x 3 - 1 1/4"	Brass	15
4255750506357	ECOPFUA4006	40 x 3,5 - 1"	Brass	10
4255750506364	ECOPFUA4007	40 x 3,5 - 1 1/4"	Brass	10
4255750506371	ECOPFUA5008	50 x 4 - 1 1/2"	Brass	5
4255750506388	ECOPFUA6309	63 x 4,5 - 2"	Brass	2

**PRESS CONNECTOR WITH FEMALE THREAD**

GTIN NO. (EAN)	ITEM NO.	SIZE	MATERIAL	
4255750506395	ECOPFUI1604	16 x 2 - 1/2"	Brass	60
4255750506401	ECOPFUI2004	20 x 2 - 1/2"	Brass	60
4255750506418	ECOPFUI2005	20 x 2 - 3/4"	Brass	45
4255750506425	ECOPFUI2605	26 x 3 - 3/4"	Brass	25
4255750506432	ECOPFUI2606	26 x 3 - 1"	Brass	25
4255750506449	ECOPFUI3206	32 x 3 - 1"	Brass	15
4255750506456	ECOPFUI3207	32 x 3 - 1 1/4"	Brass	15
4255750506463	ECOPFUI4006	40 x 3,5 - 1"	Brass	10
4255750506470	ECOPFUI4007	40 x 3,5 - 1 1/4"	Brass	10
4255750506487	ECOPFUI5008	50 x 4 - 1 1/2"	Brass	5
4255750506494	ECOPFUI6309	63 x 4,5 - 2"	Brass	2



PRESS ELBOW 90°



GTIN NO. (EAN)	ITEM NO.	SIZE	MATERIAL	
4260494175165	KPFW1616	16 x 2	PPSU	40
4260494175172	KPFW2020	20 x 2	PPSU	30
4260494175189	KPFW2626	26 x 3	PPSU	20
4260494175196	KPFW3232	32 x 3	PPSU	10
4255750506623	ECOPFW4040	40 x 3,5	Brass	10
4255750506630	ECOPFW5050	50 x 4	Brass	5
4255750506647	ECOPFW6363	63 x 4,5	Brass	2



PRESS ELBOW 45°



GTIN NO. (EAN)	ITEM NO.	SIZE	MATERIAL	
4255750506739	ECOPFWH2626	26 x 3	Brass	20
4255750506746	ECOPFWH3232	32 x 3	Brass	10
4255750506753	ECOPFWH4040	40 x 3,5	Brass	10
4255750506760	ECOPFWH5050	50 x 4	Brass	5
4255750506777	ECOPFWH6363	63 x 4,5	Brass	2



PRESS ELBOW WITH MALE THREAD



GTIN NO. (EAN)	ITEM NO.	SIZE	MATERIAL	
4255750506654	ECOPFWA1604	16 x 2 - 1/2"	Brass	40
4255750506661	ECOPFWA2004	20 x 2 - 1/2"	Brass	40
4255750506678	ECOPFWA2005	20 x 2 - 3/4"	Brass	30
4255750506685	ECOPFWA2605	26 x 3 - 3/4"	Brass	20
4255750506692	ECOPFWA3206	32 x 3 - 1"	Brass	10
4255750506708	ECOPFWA4007	40 x 3,5 - 1 1/4"	Brass	10

**PRESS ELBOW WITH FEMALE THREAD**

GTIN NO. (EAN)	ITEM NO.	SIZE	MATERIAL	
4255750506784	ECOPFWI1604	16 x 2 - 1/2"	Brass	40
4255750506791	ECOPFWI2004	20 x 2 - 1/2"	Brass	40
4255750506807	ECOPFWI2005	20 x 2 - 3/4"	Brass	30
4255750506814	ECOPFWI2605	26 x 3 - 3/4"	Brass	20
4255750506821	ECOPFWI3206	32 x 3 - 1"	Brass	10
4255750506838	ECOPFWI4007	40 x 3,5 - 1 1/4"	Brass	10

**PRESS T-CONNECTOR**

GTIN NO. (EAN)	ITEM NO.	SIZE	MATERIAL	
4260494175127	KPFT161616	16 x 2	PPSU	25
4260494175134	KPFT202020	20 x 2	PPSU	20
4260494175141	KPFT262626	26 x 3	PPSU	10
4260494175158	KPFT323232	32 x 3	PPSU	5
4255750505978	ECOPFT404040	40 x 3,5	Brass	5
4255750506036	ECOPFT505050	50 x 4	Brass	2
4255750506067	ECOPFT636363	63 x 4,5	Brass	2


**PRESS T-CONNECTOR, ENLARGED CENTRAL OUTLET**

GTIN NO. (EAN)	ITEM NO.	SIZE	MATERIAL	
4260494178937	KPFT162016	16 x 2 - 20 x 2 - 16 x 2	PPSU	25
4260494178975	KPFT202620	20 x 2 - 26 x 3 - 20 x 2	PPSU	10
4255750505886	ECOPFT263226	26 x 3 - 32 x 3 - 26 x 3	Brass	10




PRESS REDUCED T-CONNECTOR



GTIN NO. (EAN)	ITEM NO.	SIZE	MATERIAL	
4260494178944	KPFT201616	20 x 2 - 16 x 2 - 16 x 2	PPSU	25
4260494178968	KPFT202016	20 x 2 - 20 x 2 - 16 x 2	PPSU	25
4260494178982	KPFT261620	26 x 3 - 16 x 2 - 20 x 2	PPSU	10
4260494179002	KPFT262016	26 x 3 - 20 x 2 - 16 x 2	PPSU	10
4260494179019	KPFT262020	26 x 3 - 20 x 2 - 20 x 2	PPSU	10
4260494179033	KPFT262616	26 x 3 - 26 x 3 - 16 x 2	PPSU	10
4260494179040	KPFT262620	26 x 3 - 26 x 3 - 20 x 2	PPSU	10
4255750505893	ECOPFT322026	32 x 3 - 20 x 2 - 26 x 3	Brass	10
4260494179071	KPFT322626	32 x 3 - 26 x 3 - 26 x 3	PPSU	10
4255750505909	ECOPFT323226	32 x 3 - 32 x 3 - 26 x 3	Brass	10
4255750505923	ECOPFT402632	40 x 3,5 - 26 x 3 - 32 x 3	Brass	5
4255750505947	ECOPFT403232	40 x 3,5 - 32 x 3 - 32 x 3	Brass	5
4255750505961	ECOPFT404032	40 x 3,5 - 40 x 3,5 - 32 x 3	Brass	5
4255750506005	ECOPFT504040	50 x 4 - 40 x 3,5 - 40 x 3,5	Brass	2
4255750506029	ECOPFT505040	50 x 4 - 50 x 4 - 40 x 3,5	Brass	2

PRESS T-CONNECTOR REDUCED CENTRAL OUTLET



GTIN NO. (EAN)	ITEM NO.	SIZE	MATERIAL	
4260494178951	KPFT201620	20 x 2 - 16 x 2 - 20 x 2	PPSU	25
4260494178999	KPFT261626	26 x 3 - 16 x 2 - 26 x 3	PPSU	10
4260494179026	KPFT262026	26 x 3 - 20 x 2 - 26 x 3	PPSU	10
4260494179057	KPFT321632	32 x 3 - 16 x 2 - 32 x 3	PPSU	10
4260494179064	KPFT322032	32 x 3 - 20 x 2 - 32 x 3	PPSU	10
4260494179088	KPFT322632	32 x 3 - 26 x 3 - 32 x 3	PPSU	10
4255750505916	ECOPFT402040	40 x 3,5 - 20 x 2 - 40 x 3,5	Brass	5
4255750505930	ECOPFT402640	40 x 3,5 - 26 x 3 - 40 x 3,5	Brass	5
4255750505954	ECOPFT403240	40 x 3,5 - 32 x 3 - 40 x 3,5	Brass	5
4255750505985	ECOPFT502650	50 x 4 - 26 x 3 - 50 x 4	Brass	2
4255750505992	ECOPFT503250	50 x 4 - 32 x 3 - 50 x 4	Brass	2
4255750506012	ECOPFT504050	50 x 4 - 40 x 3,5 - 50 x 4	Brass	2
4255750506043	ECOPFT634063	63 x 4,5 - 40 x 3,5 - 63 x 4,5	Brass	2
4255750506050	ECOPFT635063	63 x 4,5 - 50 x 4 - 63 x 4,5	Brass	2

**PRESS T-CONNECTOR WITH FEMALE THREAD**

GTIN NO. (EAN)	ITEM NO.	SIZE	MATERIAL	
4255750506166	ECOPFTI160416	16 x 2 - 1/2" - 16 x 2	Brass	25
4255750506173	ECOPFTI200420	20 x 2 - 1/2" - 20 x 2	Brass	20
4255750506180	ECOPFTI200520	20 x 2 - 3/4" - 20 x 2	Brass	20
4255750506197	ECOPFTI260426	26 x 3 - 1/2" - 26 x 3	Brass	10
4255750506203	ECOPFTI260526	26 x 3 - 3/4" - 26 x 3	Brass	10
4255750506210	ECOPFTI320432	32 x 3 - 1/2" - 32 x 3	Brass	10
4255750506227	ECOPFTI320532	32 x 3 - 3/4" - 32 x 3	Brass	10
4255750506234	ECOPFTI320632	32 x 3 - 1" - 32 x 3	Brass	10
4255750506241	ECOPFTI400640	40 x 3,5 - 1" - 40 x 3,5	Brass	5
4255750506258	ECOPFTI400740	40 x 3,5 - 1 1/4" - 40 x 3,5	Brass	5
4255750506265	ECOPFTI500750	50 x 4 - 1 1/4" - 50 x 4	Brass	2
4255750506272	ECOPFTI500850	50 x 4 - 1 1/2" - 50 x 4	Brass	2


**PRESS T-CONNECTOR WITH MALE THREAD**

GTIN NO. (EAN)	ITEM NO.	SIZE	MATERIAL	
4255750506074	ECOPFTA160416	16 x 2 - 1/2" - 16 x 2	Brass	25
4255750506081	ECOPFTA200420	20 x 2 - 1/2" - 20 x 2	Brass	20
4255750506098	ECOPFTA200520	20 x 2 - 3/4" - 20 x 2	Brass	20
4255750506104	ECOPFTA260426	26 x 3 - 1/2" - 26 x 3	Brass	10
4255750506111	ECOPFTA260526	26 x 3 - 3/4" - 26 x 3	Brass	10
4255750506128	ECOPFTA260626	26 x 3 - 1" - 26 x 3	Brass	10
4255750506135	ECOPFTA320532	32 x 3 - 3/4" - 32 x 3	Brass	10
4255750506142	ECOPFTA320632	32 x 3 - 1" - 32 x 3	Brass	10




PRESS COUPLING



GTIN NO. (EAN)	ITEM NO.	SIZE	MATERIAL	
4260494175059	KPFK1616	16 x 2 - 16 x 2	PPSU	50
4260494175073	KPFK2020	20 x 2 - 20 x 2	PPSU	40
4260494175097	KPFK2626	26 x 3 - 26 x 3	PPSU	25
4260494175110	KPFK3232	32 x 3 - 32 x 3	PPSU	15
4255750505770	ECOPFK4040	40 x 3,5 - 40 x 3,5	Brass	15
4255750505800	ECOPFK5050	50 x 4 - 50 x 4	Brass	5
4255750505831	ECOPFK6363	63 x 4,5 - 63 x 4,5	Brass	2

PRESS REDUCED COUPLING



GTIN NO. (EAN)	ITEM NO.	SIZE	MATERIAL	
4260494175066	KPFK2016	20 x 2 - 16 x 2	PPSU	40
4255750505725	ECOPFK2616	26 x 3 - 16 x 2	Brass	25
4260494175080	KPFK2620	26 x 3 - 20 x 2	PPSU	25
4255750505732	ECOPFK3216	32 x 3 - 16 x 2	Brass	25
4255750505749	ECOPFK3220	32 x 3 - 20 x 2	Brass	25
4260494175103	KPFK3226	32 x 3 - 26 x 3	PPSU	25
4255750505756	ECOPFK4026	40 x 3,5 - 26 x 3	Brass	15
4255750505763	ECOPFK4032	40 x 3,5 - 32 x 3	Brass	15
4255750505787	ECOPFK5032	50 x 4 - 32 x 3	Brass	5
4255750505794	ECOPFK5040	50 x 4 - 40 x 3,5	Brass	5
4255750505817	ECOPFK6340	63 x 4,5 - 40 x 3,5	Brass	2
4255750505824	ECOPFK6350	63 x 4,5 - 50 x 4	Brass	2

**PRESS END PLUG**

GTIN NO. (EAN)	ITEM NO.	SIZE	MATERIAL	
4255750505848	ECOPFS16	16 x 2	Brass	75
4255750505855	ECOPFS20	20 x 2	Brass	75
4255750505862	ECOPFS26	26 x 3	Brass	50
4255750505879	ECOPFS32	32 x 3	Brass	30

PRESS WALL ELBOW

GTIN NO. (EAN)	ITEM NO.	SIZE	MATERIAL	
4255750506845	ECOPFWWK1604	16 x 2 - 1/2" - 39 mm	Brass	25
4255750506876	ECOPFWWM1604	16 x 2 - 1/2" - 52 mm	Brass	20
4255750506852	ECOPFWWL1604	16 x 2 - 1/2" - 78 mm	Brass	15
4255750506883	ECOPFWWM2004	20 x 2 - 1/2" - 52 mm	Brass	20
4255750506869	ECOPFWWL2004	20 x 2 - 1/2" - 78 mm	Brass	15
4255750506890	ECOPFWWM2005	20 x 2 - 3/4" - 52 mm	Brass	15
4255750506906	ECOPFWWM2605	26 x 3 - 3/4" - 52 mm	Brass	15

PRESS WALL ELBOW – DOUBLE – U-SHAPED CURVED

GTIN NO. (EAN)	ITEM NO.	SIZE	MATERIAL	
4255750506913	ECOPFWUSA160416	16 x 2 - 1/2" - 16 x 2	Brass	5
4255750506920	ECOPFWUSA200420	20 x 2 - 1/2" - 20 x 2	Brass	5



PRESS WALL BUSHING WITH FEMALE THREAD




GTIN NO. (EAN)	ITEM NO.	SIZE	MATERIAL	
4255750506715	ECOPFWDF1604	16 x 2 mm - 1/2"	Brass	10
4255750506722	ECOPFWDF2004	20 x 2 mm - 1/2"	Brass	10



PRESS TOILET CONNECTION



GTIN NO. (EAN)	ITEM NO.	SIZE	MATERIAL	
4255750506159	ECOPFTC16	16 x 2 mm - 1/2"	Brass	15



PRESS CONNECTOR SCREW CONNECTOR WITH FEMALE THREAD



GTIN NO. (EAN)	ITEM NO.	SIZE	MATERIAL	
4255750506500	ECOPFV1604	16 x 2 - 1/2"	Brass	50
4255750506517	ECOPFV1605	16 x 2 - 3/4"	Brass	50
4255750506524	ECOPFV2004	20 x 2 - 1/2"	Brass	40
4255750506531	ECOPFV2005	20 x 2 - 3/4"	Brass	40
4255750506548	ECOPFV2006	20 x 2 - 1"	Brass	30
4255750506555	ECOPFV2605	26 x 3 - 3/4"	Brass	25
4255750506562	ECOPFV2606	26 x 3 - 1"	Brass	25
4255750506579	ECOPFV3206	32 x 3 - 1"	Brass	15
4255750506586	ECOPFV3207	32 x 3 - 1 1/4"	Brass	15
4255750506593	ECOPFV3208	32 x 3 - 1 1/2"	Brass	15
4255750506609	ECOPFV4007	40 x 3,5 - 1 1/4"	Brass	10
4255750506616	ECOPFV4008	40 x 3,5 - 1 1/2"	Brass	10